

SPARE PARTS EXPLODED VIEW GAS-WALL CONDENSING BOILERS


Model


BLUETTE 107.24

R8216283-05 - 02/10/2013


1	3123774	BLUETTE 107.24 CPR MET	05-2008	12-2011
1	3123778	BLUETTE 107.24 CPR GPL	05-2008	12-2011
2	3123775	BLUETTE 107.24 SP/A MET	05-2008	12-2011
2	3123779	BLUETTE 107.24 SP/A GPL	05-2008	12-2011
3	3123776	BLUETTE 107.24 CPA MET	05-2008	12-2011
3	3123780	BLUETTE 107.24 CPA GPL	05-2008	12-2011
4	3123777	BLUETTE 107.24 CPA COLONNA MET	06-2008	03-2012
4	3123781	BLUETTE 107.24 CPA COLONNA GPL	06-2008	03-2012

Col	Reference	Model type	Begin	End
-----	-----------	------------	-------	-----






CPR-SP/A




CPA



Gas-wall condensing boilers




CPR




501



SP/A






CPA





	Description	Manf. Pt. N	Type	BLUETTE 107.24 CPR BLUETTE 107.24 SP/A BLUETTE 107.24 CPA BLUETTE 107.24 CPA COL 31																	
				1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18
0500	WATER SECTION ASSY																				
0501	DISTRIBUTION GROUP (RETURN)	65100943			•		•														
	HEATING BLOCK ASSY	65070211					•														
	RETURN GROUP	65070011			•																
0502	MOTOR (3-WAY VALVE)	997147			•		•														
0503	DELIVERY PIPE	65100959			•																
	PIPE (C.H. FLOW)	65108234				•		•													
0504	PLUG	65108232			•																
0505	C.H.W. FLOW PIPE	65070210					•														
0509	DIAPHRAGM (MAIN FLOW SWITCH)	571547			•		•														
0510	PIPE (D.H.W. OUTLET)	65070219					•														
0511	PIPE (COLD WATER INLET)	65070221					•														
0515	BY-PASS	65070652					•														
	BY-PASS	996046			•	•		•													
0516	DISTRIBUTION GROUP (C.H.FLOW)	65100942				•		•													
	FLOW GROUP	65105060			•																
0520	NTC PROBE (FLOW/RETURN)	65070016				•		•													
	SENSOR NTC 1/8, 10kOhm Beta 3977	65070018			•		•														
0529	PRESSURE GAUGE	571649			•	•	•	•													
0530	SUPPORT (PRESSURE GAUGE)	999880			•	•	•	•													
0531	AUTO AIR VENT	65070014			•	•	•	•													
0532	FILLING TAP KIT	571445			•		•														
0533	PIPE (C.H. RETURN)	65070230					•														
	PIPE (C.H. RETURN)	65070245			•																
	PIPE (C.H. RETURN)	65108233				•		•													
0534	UNION CL ART. 2520 1/8 M -1/4 F	65104962				•		•													
0535	BY-PASS PIPE	65100949			•	•		•													
0536	SAFETY VALVE (8 BAR)	569377					•														
0537	SAFETY VALVE (1/2 M/F 3 BAR)	571004					•														
	SAFETY VALVE (3 BAR)+MANOMETRO	998453			•	•		•													
0538	PUMP	65070013			•	•		•													
	PUMP	65070209					•														
0539	MAIN FLOW SWITCH KIT	65100519			•		•														
0540	FILLING COCK KNOB	571559			•		•														
0543	PIPE (NEGATIVE SIGNAL)	65100952			•																
0544	PIPE (POSITIVE SIGNAL)	65100951			•																
0563	AIR VALVE FITTING	65107448				•		•													
	DRAIN VALVE	573727			•		•														
0567	3-WAY SPRING KIT (D.H.W.)	998975			•																
0568	3-WAY SPRING KIT (C.H.)	65105065			•																
	ASSEMBLED SHUTTER	65105144					•														
0571	LOW WATER PRESSURE SWITCH	995903				•		•													
0574	SPRING (BY-PASS PIPE)	998064			•	•		•													
0575	O-RING	998077			•	•		•													
0589	DHW HEAT EXCHANGER	998483			•																
0590	O-RING 4075 3,53 X 18,64	573825			•																
0591	SPINDLE	65070651					•														
0592	D.H.W. ACTUATOR KIT	571444			•																

600



Gas-wall condensing boilers



716

713

737

726

715






760

782

782

758


703



727

733

Gas-wall condensing boilers



818

Gas-wall condensing boilers

LIST OF THE ABBREVIATIONS

HW	: Hot water.
CW	: Cold water.
C	: Ceramic resistance (normal heating).
Ca	: Ceramic resistance (accelerated heating)
TP	: Immersion heater.
1F	: With fittings.
2F	: Without fittings.
3F	: With fittings and another outlet connection.
AMI	: With mixing valve.
SMI	: Without mixing valve.
PUISS	: Power of th appliance.
PN	: Appliance with normal pression.
LP	: Appliance with low pression.
PV	: Appliance with variable power.
PF	: Appliance with fixed power.

IDENTIFICATION PLATE

SERIAL NUMBER

10 Characters :	04 05 125 011	
		Sequential number
		Manufacturing day
		Year of manufacture
11 Characters :	1 95 065004 - 31	
Month of manufacture : from 1 to 9 → Jan. to Sep., O → Oct., N → Nov., D → Dec.		Technical number of the appliance
		Sequential number
		Year of manufacture
19 Characters :	08 05 0013199 900640031	
Year of manufacture		Product reference
Month of manufacture		Sequential number
20 Characters :	3675007 XX 2 07 070 00315	
Product reference		Sequential number
Millenium of manufacture		Manufacturing day
		Year of manufacture
21 Characters :	3675007 XX 07 070 0000315	
Product reference		Sequential number
Year of manufacture		Manufacturing day