

SPARE PARTS EXPLODED VIEW GAS WALL BOILERS


Model

CERAR


R8202315-04 - 04/07/2012

1	54225131	CERAR VENTI TOP NAT	01-1988	06-1995
1	54225121	CERAR VENTI TOP B/P	01-1988	06-1995
2	54225137	CERAR VENTI FF TOP NAT	01-1988	06-1995
2	54225127	CERAR VENTI FF TOP B/P	01-1988	06-1995
3	54225132	CERAR VENTI TOP FFa NAT	01-1988	06-1995
3	54225122	CERAR VENTI TOP FFa B/P	01-1988	06-1995
4	54224921	CERAR VENTI B/P	01-1988	06-1995
4	54224931	CERAR VENTI NAT	01-1988	06-1995
5	54224937	CERAR VENTI FF NAT	01-1988	06-1995
5	54224927	CERAR VENTI FF B/P	01-1988	06-1995
6	56224931	CORTINA E NAT PENSOTTI	01-1988	06-1995
6	56224921	CORTINA E B/P PENSOTTI	01-1988	06-1995
7	56224937	CORTINA FE NAT PENSOTTI	01-1988	06-1995
7	56224927	CORTINA FE B/P PENSOTTI	01-1988	06-1995
8	51224931	RS 20 Me NAT ELECTA	01-1988	06-1995
8	51224921	RS 20 Me B/P ELECTA	01-1988	06-1995
9	51224937	RS 20 Me FF NAT ELECTA	01-1988	06-1995
9	51224927	RS 20 Me FF B/P ELECTA	01-1988	06-1995
10	55224931	M 20 e NAT NOVOGAS	01-1988	06-1995
10	55224921	M 20 e B/P NOVOGAS	01-1988	06-1995
11	55224937	M 20 FF e NAT NOVOGAS	01-1988	06-1995
11	55224927	M 20 FF e B/P NOVOGAS	01-1988	06-1995
12	54225831	CERAR VENTIGUATRO TOP NAT	01-1988	06-1995
12	54225821	CERAR VENTIGUATRO TOP B/P	01-1988	06-1995
Col	Reference	Model type	Begin	End


100





200






300



400




☰	Description	Manf. Pt. N	Type	CERAR VENTI TOP CF CERAR VENTI TOP FF CERAR VENTI TOP FFa CERAR VENTI CF CORTINA E Pensotti FF CORTINA FE Pensotti CF RS 20 Me Pensotti FF RS 20 Me Eletta CF M 20 e Eletta FF M 20 e NOVOCAS CF CERAR VENTICUATRO CF																		31
				1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	
0100	CHASSIS																					
0103	TRAPPED NUT M 6	60004806-03		•	•	•	•	•	•	•	•	•	•	•								
0200	HEATING BODY	60042522		•	•	•	•	•	•	•	•	•	•									
	HEATING BODY	60042523												•								
0201	HEAT EXCHANGER	60078242-06		•	•	•	•	•	•	•	•	•	•	•								
	HEAT EXCHANGER	60078243-06												•								
0202	O-RING D: 16.1-1.6	60024184-35		•	•	•	•	•	•	•	•	•	•	•								
0203	COMBUSTION CHAMBER LINING KIT	60081001		•	•	•	•	•	•	•	•	•	•	•								
	COMBUSTION CHAMBER LINING KIT	60081137												•								
0204	COMBUSTION CHAMBER KIT	60081002		•	•	•	•	•	•	•	•	•	•	•								
	COMBUSTION CHAMBER KIT	60081130												•								
0205	TAPPING SCREW CBLSX D: 4.2-9.5	61010125		•	•	•	•	•	•	•	•	•	•	•								
0207	TAPPING SCREW CBLSX D: 6.3-13	61010648		•	•	•	•	•	•	•	•	•	•	•								
0300	DRAUGHT DIVERTER	60078170		•			•		•		•		•									
0305	OVERHEAT THERMOSTAT 63C	61008820		•					•		•			•					05/93			
0306	SENSOR SUPPORT	61008824		•					•		•			•					05/93			
0307	TAPPING SCREW CBLZ D: 3.5-6.5	60031521-03		•					•		•			•								
0400	SEALED CASE																					
0402	BASE - BOX	60077841			•			•		•		•		•								
0403	SIDE PANEL	60072448			•	•				•		•		•								
0405	SIGHT GLASS ASSY	60081047			•	•		•		•		•		•								
0406	SILICONE FOAM SEAL 7x7 L: 2.5M	60081273-03			•	•		•		•		•		•								
0407	SCREW HS M 6-15	60019316-03			•	•		•		•		•		•								
0409	FOAM SEAL 12.5x5 L: 2.5M	60081273			•	•		•		•		•		•								
0410	SILICONE FOAM SEAL 10x3 L: 1M	60081273-05			•	•		•		•		•		•								
0411	WASHER D: 12-6.2-1.2	60007059-03			•	•				•		•		•								
0412	WASHER D: 11.5-6.2-1	60034377			•	•				•		•		•								
0414	TAPPING SCREW CBLZ D: 4.8-16	60061015			•	•		•		•		•		•								
0416	SILICONE TUBE D: 6x1 L: 1.30M	60081265-04				•																
0417	TAPPING SCREW CLS D: 3.9-19	60061982				•																
0419	WASHER D: 10-5-1	60022118-03				•																
0420	NUT H M 5-0.80	60008664-13				•																




CERAR


600




700





1000




1200







1100



	Description	Manf. Pt. N	Type	CERAR VENTI TOP CF CERAR VENTI TOP FF CERAR VENTI TOP FFa CERAR VENTI CF CORTINA E CORTINA FE RS 20 Me Eletta CF RS 20 Me Eletta FF M 20 e NOVOCAS CF M 20 e NOVOCAS FF CERAR VENTQUATRO CF 31																	
				1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18
0600	BURNER HEAD	60079368		•	•	•			•	•	•	•									
0601	TAPPING SCREW CBLX D: 6.3-13	61010648		•		•	•		•				•		•						
0602	CROSS LIGHTING STRIP	60074656														•					
	CROSS LIGHTING STRIP	60079410		•	•	•	•	•	•	•	•	•	•	•	•						
0605	TAPPING SCREW CBLZ D: 3.5-6.5	60031521-03		•	•	•			•	•	•	•			•						
0606	IGNITION ELECTRODE ASSY	60077790					•	•					•	•							
	IGNITION ELECTRODE ASSY	61004019		•	•	•			•	•	•	•			•						
0607	IONIZATION ELECTRODE ASSY	60078258		•	•	•	•	•	•	•	•	•	•	•	•						
0700	MANIFOLD																				
0701	MANIFOLD LPG KIT	60081012	GPL	•	•	•	•				•	•	•								
	MANIFOLD LPG KIT	60081059	GPL					•	•						•						
	MANIFOLD NAT KIT	60081011	MET	•	•	•	•		•		•	•	•	•							
	MANIFOLD NAT KIT	60081058	MET					•							•						
	MANIFOLD NAT KIT	60081364	MET													•					
0702	GASKET (/Manifold)	60071226		•	•	•	•	•	•	•	•	•	•	•	•						
0703	SCREW HX M 5-12	61010131		•	•	•	•	•	•	•	•	•	•	•	•						
0704	WASHER D: 12-5.2-1	60061934-03		•	•	•	•	•	•	•	•	•	•	•	•						
0705	TAPPING SCREW CBLX D: 4.2-25	61010128		•	•	•	•	•	•	•	•	•	•	•	•						
0706	CLOSURE PLATE	60060727			•	•				•		•									
1000	EXPANSION VESSEL	60056676-06		•	•	•	•	•	•	•	•	•	•	•	•						
1001	FLEXIBLE PIPE KIT	60081013		•	•	•	•	•	•	•	•	•	•	•	•						
1002	EXPANSION VESSEL SUPPORT KIT	60081014					•				•		•		•						
	EXPANSION VESSEL SUPPORT KIT	60081045			•	•		•			•		•		•						
1003	COMPRESSION OLIVE D: 6	60022865		•	•	•	•	•	•	•	•	•	•	•	•						
1004	CONNECTING NUT	60031269		•	•	•	•	•	•	•	•	•	•	•	•						
1100	WATER FLOW SWITCH HPS KIT	61004104						•							•						
1101	WATER FLOW SWITCH	61000658			•	•				•		•									
1103	MICRO SWITCH BOX	60078619						•							•						
1104	CABLE : WATER FLOW SWITCH	61000731			•	•				•		•									
1105	BEARING PLATE ASSY	60081558						•							•						
1106	DIAPHRAGM	60010419						•							•						
1107	SHEET GASKET D: 13.9-10.4-1.5	60061853-02						•							•						
	SHEET GASKET D: 11-5-1.5	60061853-07			•	•				•		•			•						
1108	PLUG	60074358						•							•						
1109	SHEET GASKET D: 14.8-10.3-1.5	60061854-11						•							•						
1110	GLAND	60022639						•							•						
1112	NUT M 6-1	60017460-03						•							•						
1115	HIGH PRESSURE TUBE	61000660			•																
	HIGH PRESSURE TUBE	61001473								•		•									
1116	LOW PRESSURE TUBE	60079053						•							•						
	LOW PRESSURE TUBE	61001474			•	•				•		•									
1117	O-RING D: 6-1	60024164-41			•	•				•		•									
1200	WATER / WATER HEAT EXCHANGER	61001974		•	•	•	•	•	•	•	•	•	•	•	•						
1201	O-RING D: 16-1.9	60024183-37		•	•	•	•	•	•	•	•	•	•	•	•						
1203	SCREW HS M 8-16	60031519-03		•	•	•	•	•	•	•	•	•	•	•	•						





Domestic Gas Boilers




CERAR



1500




1600




1700





1800








1900



2000



	Description	Manf. Pt. N	Type	CERAR VENTI TOP CF CERAR VENTI TOP FF CERAR VENTI TOP FFa CERAR VENTI CF CORTINA FF CORTINA FE Pensoli CF RS 20 Me Eletta CF RS 20 Me Eletta FF M 20 e NOVOCAS CF M 20 e NOVOCAS FF CERAR VENTIQUATTRO CF 31																	
				1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18
1500	GAS TUBE	60074041	GPL	•			•		•		•		•		•						
	GAS TUBE	60062316	MET					•							•						
1501	SHEET GASKET D: 24-18.2-1.5	60022835-01		•	•	•	•	•	•	•	•	•	•	•	•						
1502	GAS GOVERNOR	60075742	MET	•					•		•										
	GAS GOVERNOR	60078924	MET		•	•	•	•		•		•	•	•							
1600	COLD WATER TUBE C.O.V. TO EXC.	60078128		•	•	•	•	•	•	•	•	•	•	•	•						
1601	O-RING D: 16-1.9	60024183-37		•	•	•	•	•	•	•	•	•	•	•	•						
1602	SHEET GASKET D: 29.6-22-1.5	60061856-14		•	•	•	•	•	•	•	•	•	•	•	•						
1700	TUBE - C.O.V. TO HEATING BODY	60078126-08		•			•		•		•		•								
	TUBE - C.O.V. TO HEATING BODY	60079101-08														•					
	TUBE - C.O.V. TO HEATING BODY	60079351-08			•	•		•		•		•		•							
1701	NUT M 14-0.75	60064552		•	•	•	•	•	•	•	•	•	•	•	•						
1703	CLIP	60078502		•	•	•			•		•	•	•	•							
1705	O-RING D: 16.1-1.6	60024184-35		•	•	•	•	•	•	•	•	•	•	•	•						
1706	GROMMET D: 18	60072075			•	•		•		•		•		•							
1711	OVERHEAT THERMOSTAT 110C	60070773			•	•				•		•		•							
1712	TAPPING SCREW CBLZ D: 3.5-6.5	60031521-03			•	•				•		•									
1800	FILLER NECK	60078123		•	•	•	•	•	•	•	•	•	•	•	•						
1801	O-RING D: 6-1	60024164-41		•	•	•	•	•	•	•	•	•	•	•	•						
1900	TUBE - PUMP TO HEAT EXCHANGER																				
1901	FLEXIBLE PIPE	61004681								•		•									
	FLEXIBLE PIPE	61004705			•																
1902	TUBE : PUMP TO HEAT EXCHANGER	60079055-08						•							•						
	TUBE : PUMP TO HEAT EXCHANGER	61001552							•		•										
	TUBE : PUMP TO HEAT EXCHANGER	61001574		•																	
	TUBE : PUMP TO HEAT EXCHANGER	61004047					•							•		•					
	TUBE : PUMP TO HEAT EXCHANGER	61004680			•					•		•									
1905	O-RING D: 16-5	60024959-12			•				•	•	•	•									
1906	CLIP	60031764			•		•	•	•	•	•	•	•	•	•						
2000	SHORT CIRCUIT TUBE	60072476		•	•	•	•	•	•	•	•	•	•	•	•						




2103




2102




2114



2127



2120



2106



2107



2118



2117














2126













CERAR

2200



2206



	Description	Manf. Pt. N	Type	CERAR VENTI TOP CF CERAR VENTI TOP FF CERAR VENTI TOP FFa CERAR VENTI CF CORTINA E Pensotti FF CORTINA FE Pensotti CF RS 20 Me Eletta CF RS 20 Me Eletta FF M 20 e NOVOCAS CF M 20 e NOVOCAS FF CERAR VENTQUATTRO CF																		31		
				1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18			
2200	ELECTRICAL BOX	60078518		●						●											04/91	04/93		
	ELECTRICAL BOX	60078518				●					●													
	ELECTRICAL BOX	60078518					●														07/91	04/93		
	ELECTRICAL BOX	60078518												●							04/92	04/93		
	ELECTRICAL BOX	61008830		●				●		●				●							05/93			
2201	PRINT CIRCUIT BOARD MOT 1V KIT	60081492				●	●					●	●											
	PRINTED CIRCUIT BOARD	61004599		●	●	●			●	●	●	●			●									
2202	PRINTED CIRCUIT BOARD	61004219		●	●	●			●	●	●	●			●									
2203	POTENTIOMETER	60078577		●	●	●		●	●	●	●	●	●	●	●									
2204	NUT H 10-0.75	60078576		●	●	●		●	●	●	●	●	●	●	●									
2205	FUSE HOLDER	60044799-10		●	●	●		●	●	●	●	●	●	●	●									
2206	PROTECTIVE CAP	60044800-10		●	●	●		●	●	●	●	●	●	●	●									
2207	FUSE 250V 2A	60054442		●	●	●		●	●	●	●	●	●	●	●									
2208	IGNITER	60071266					●	●					●	●										
	IGNITER	61002105-20		●	●	●			●		●	●			●									
2211	CLIP	60074039					●	●					●	●										
2214	AQUASTAT 57C KIT	60100606-30		●	●	●		●	●	●	●	●	●	●	●									
2215	HEATING LIMIT THERMOSTAT 85C	60056974		●	●	●		●	●	●	●	●	●	●	●									
2221	EARTH TERMINAL	60045227					●	●					●	●										
	EARTH SCREW KIT	60081169		●	●																04/91	05/93		
	EARTH SCREW KIT	60081169									●	●									04/91	05/93		
	EARTH SCREW KIT	60081169							●	●											07/91	05/93		
	EARTH SCREW KIT	60081169														●					04/92	05/93		
	CONNECTION STRIP	61002725				●																		
	CONNECTION STRIP	61002725		●	●			●		●	●	●	●		●						06/93			
2223	CIRCUIT BREAKER	60070852		●	●	●		●	●	●	●	●	●	●	●									
2225	BLACK SWITCH	60078572-10		●	●	●			●	●	●	●			●									
	WHITE SWITCH	60078980-10					●	●					●	●										
2227	CAPACITOR	60070779					●	●					●	●										
2229	CONNECTOR	60074977					●	●					●	●										
2232	O-RING D: 7.2-1.9	60024164-12		●	●	●		●	●	●	●	●	●	●	●									
2233	CLIP	60031546		●	●	●		●	●	●	●	●	●	●	●									
2234	CLIP	60078502		●	●	●		●	●	●	●	●	●	●	●									
2235	NUT H M 6-1	60026501-03		●	●	●		●	●			●	●	●	●									
2236	GROMMET	60027837		●	●	●		●	●	●	●	●	●	●	●									
2240	ELECTRICAL BOX COVER	60078052		●	●	●		●	●	●	●	●	●	●	●									
2244	ELECTRICAL BOX SUPPORT	60079087				●	●																	
2249	SCREW F90Z D: 3.5-16	61004804-20		●	●	●		●	●	●	●	●	●	●	●									
2250	GROMMET	60027838		●	●	●		●	●	●	●	●	●	●	●									
2253	TAPPING SCREW CBL SX D: 6.3-13	61010648		●	●	●		●	●	●	●	●	●	●	●									
2254	SCREW HS M 6-25	60010942-13		●		●		●	●	●	●	●	●	●	●									

2213

2209

2210

2228

12/87 --> 04/91

2209

05/91 --> 12/95

2219

2218

2216

2217

2222

2224

2226



2251

2257

2261





2260

CERAR




CERAR

2700




2900




☰	Description	Manf. Pt. N	Type	CERAR VENTI TOP CF CERAR VENTI TOP FF CERAR VENTI TOP Ffa CERAR VENTI CF CERAR VENTI FF CORTINA E Pensoli CF CORTINA FE Pensoli CF RS 20 Me Eletta CF RS 20 Me Eletta FF M 20 e NOVOCAS CF M 20 e NOVOCAS FF CERAR VENTICUATRO CF																		31
				1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	
2700	JIG PLATE & PIPE FITTING																					
2701	MOUNTING KIT	60081425			●					●		●										
2702	SCREW HS M 6-25	60010942-13		●		●	●	●	●	●	●	●	●	●								
2704	SCREW M 6-10	60031527-03		●			●	●	●	●	●	●	●	●	●							
2706	SHEET GASKET D: 24-16.2-1.5	60061855-02		●	●		●	●	●	●	●	●	●	●	●							
	SHEET GASKET D: 24-17-1.5	60061855-19				●																
2709	WASHER D: 18.4-12.2-1.5	60061855-14		●	●	●	●	●	●	●	●	●	●	●	●							
2710	CONNECTING PIPE	60055675		●		●			●	●	●				●							
	CONNECTING PIPE	60055675				●																
2711	SHEET GASKET D: 24-18.2-1.5	60022835-01				●									●							
	SHEET GASKET D: 24-16.2-1.5	60022835-02		●	●		●	●	●	●	●	●	●	●	●							
2715	NUT 3/4"	60020748-68		●		●	●	●	●	●	●	●	●	●	●	●						
2717	WOOD SCREW	60025617-03		●	●	●	●	●	●	●	●	●	●	●	●	●						
2718	WASHER D: 14.2-7.2-1.2	60005369-03		●	●	●	●	●	●	●	●	●	●	●	●	●						
2720	CONNECTION KIT	60079920		●			●	●	●		●		●	●	●	●						
2725	GASKET KIT	60081064		●	●	●	●	●	●	●	●	●	●	●	●	●						
2726	TAPPING SCREW CBLSX D: 4.2-9.5	61010125			●	●		●		●		●		●								
2727	WATER FILTER	61004418		●	●	●			●	●	●	●										
2732	TAPPING SCREW CBLZ D: 3.5-6.5	60031521-03						●						●								
2900	PRESSURE RELIEF VALVE																					
2901	PRESSURE RELIEF VALVE KIT	61004632		●	●	●	●	●	●	●	●	●	●	●	●	●						
2902	VALVE WASHER KIT	60081025		●	●	●	●	●	●	●	●	●	●	●	●	●						
2903	VALVE CONNECTING PIPE	60047727		●	●	●	●	●	●	●	●	●	●	●	●	●						
2905	NUT 1/2" THICK: 10	60020747-68		●	●	●	●	●	●	●	●	●	●	●	●	●						
2906	O-RING D: 13.6-2.7	60024164-18		●	●	●	●	●	●	●	●	●	●	●	●	●						
2907	GRUB SCREW	60017908		●	●	●	●	●	●	●	●	●	●	●	●	●						
2909	PRESSURE RELIEF VALVE	61020933		●	●	●	●	●	●	●	●	●	●	●	●	●						


3000



3100




3400



	Description	Manf. Pt. N	Type	CERAR VENTI TOP CF CERAR VENTI TOP FF CERAR VENTI TOP FFa CERAR VENTI CF CORTINA E CORTINA FE RS 20 Me Eletta CF RS 20 Me Eletta FF M 20 e NOVOGAS CF M 20 e NOVOGAS FF CERAR VENTQUATTRO CF 31																	
				1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18
3000	FAN ASSY 220V	60058026			•			•		•		•		•							
3001	FAN MOTOR + TURBINE 220V	60058027			•	•		•		•		•		•							
3002	FLUE HOOD	60056628						•						•							
3003	GASKET (/Cover)	60055083			•	•		•		•		•		•							
3004	SELF TAPPING SCREW M 4-15	60039054-03			•	•		•		•		•		•							
3005	FAN WASHER D: 4	60028466-03			•	•		•		•		•		•							
3007	SCREW HS M 6-12	60005799-13			•	•		•		•		•		•							
3008	SCREW CBLZ M 4-8	60057750			•	•				•		•									
3009	VENTURI	61009248				•															
3011	TAPPING SCREW CBLZ D: 3.9-9.5	60050460-03				•															
3013	FAN SUPPORT SCREW KIT	60081422			•					•		•									
3100	CONCENTRIC HORIZONTAL FLUE																				
3101	FLUE BEND TURRET	61009478				•															
3102	VENTURI ON FLUE DUCT	60060359			•			•		•		•		•							
3103	PRESSURE TEST POINT KIT	60081053			•			•		•		•		•							
3104	AIR PRESSURE SWITCH KIT	60081054			•			•		•		•		•							
3105	PRESSURE SENSI. SWITCH SUPPORT	60081369			•			•		•		•		•							
3106	PRESSURE TEST POINT KIT	60081056			•			•		•		•		•							
3107	FLUE TURRET COVER	60060418			•			•		•		•		•							
3108	GASKET	60053839			•	•		•		•		•		•							
3109	GASKET	60053840			•	•		•		•		•		•							
3110	SLEEVE	61009423				•															
3111	FLUE DUCT SECOND SECTION	60061084			•					•		•									
3112	LOCKING RING & 'O' RING KIT	60081057			•	•		•		•		•		•							
3113	GASKET (/Locking ring)	60053842			•	•		•		•		•		•							
3115	SCREW HS M 6-15	60019316-03			•	•		•		•		•		•							
3116	TAPPING SCREW CLS D: 3.9-19	60061982			•					•		•		•							
3119	SILICONE TUBE D: 6x1 L: 1.30M	60081265-04			•					•		•		•							
3120	SCREW M 5-8	60015691-03			•					•		•		•							
3153	SCREW M 3-10	60063840			•	•		•		•		•		•							
3400	ACCESSORY																				
3402	GASKET	61009109				•															

5000



CERAR

LIST OF THE ABBREVIATIONS

HW	: Hot water.
CW	: Cold water.
C	: Ceramic resistance (normal heating).
Ca	: Ceramic resistance (accelerated heating)
TP	: Immersion heater.
1F	: With fittings.
2F	: Without fittings.
3F	: With fittings and another outlet connection.
AMI	: With mixing valve.
SMI	: Without mixing valve.
PUISS	: Power of th appliance.
PN	: Appliance with normal pression.
LP	: Appliance with low pression.
PV	: Appliance with variable power.
PF	: Appliance with fixed power.

IDENTIFICATION PLATE

SERIAL NUMBER

10 Characters :	04 05 125 011	
		Sequential number
		Manufacturing day
		Year of manufacture
11 Characters :	1 95 065004 - 31	
Month of manufacture : from 1 to 9 → Jan. to Sep., O → Oct., N → Nov., D → Dec.		Technical number of the appliance
		Sequential number
		Year of manufacture
19 Characters :	08 05 0013199 900640031	
Year of manufacture		Product reference
Month of manufacture		Sequential number
20 Characters :	3675007 XX 2 07 070 00315	
Product reference		Sequential number
Millenium of manufacture		Manufacturing day
		Year of manufacture
21 Characters :	3675007 XX 07 070 0000315	
Product reference		Sequential number
Year of manufacture		Manufacturing day