



SPARE PARTS EXPLODED VIEW
GAS-WALL BOILER ATM. BURNER
Model
ECOSÍ


R8216203-05 - 28/04/2015

ECOSI CPR-SP/A









Gas-wall boiler atm. burner

1	3314025	ECOSI 25 CS CPR GPL	02-2008	05-2013
1	3314012	ECOSI 25 CS CPR MET	06-2008	05-2013
2	3314011	ECOSI 24 CA CPR MET	06-2008	05-2013
2	3314024	ECOSI 24 CA CPR GPL	02-2008	05-2011
3	3314013	ECOSI 30 CS CPR MET	06-2008	05-2013
3	3314026	ECOSI 30 CS CPR GPL	01-2009	05-2011
4	3314014	ECOSI 25 CS SP/A MET	06-2008	05-2013
Col	Reference	Model type	Begin	End




















☰	Description	Manf. Pt. N	Type	ECOSI 25 CS CPR ECOSI 24 CA CPR ECOSI 30 CS CPR ECOSI 25 CS SP/A																		31	
				1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	From	to
0200	FAN ASSEMBLY																						
0201	SUPPORT (AIR PRESSURE SWITCH)	65104378		●		●	●																
0206	FAN	65104357		●			●																
	FAN	65104452				●																	
0207	CABLE (EARTH - PUMP)	65107066		●		●																	
	EARTH WIRE	65104286					●																
0208	FAN GASKET	65104257		●		●	●																
0209	VENTURI 15/24FF	65106516		●			●																
	VENTURI 28/30FF	65106515				●																	
0210	AIR INTAKE COVER	573329		●		●	●																
0212	PANEL (INSULATION - FAN)	65104305		●		●	●																
0216	AIR PRESSURE SWITCH 50 Pa	65104671-01		●			●																
	AIR PRESSURE SWITCH 74 Pa	65104672-01				●																	
0220	CONDENSATE TRAP	65104623		●		●	●																
0300	CHASSIS-FRONT CASE																						
0303	RESTRICTOR KIT	60001598		●		●	●																
0304	FLUE (EXHAUST MANIFOLD/HEADER)	65105393		●		●	●																
0305	AIR RETURN MANIFOLD	65104710		●		●	●																
0306	AIR RETURN COVER	65104249		●		●	●																
0320	GASKET	60000317		●		●	●																
0321	GASKET 3/8»	573521		●	●	●	●																
0322	FLUE INTAKE PLUG	65104295		●		●	●																
0324	PIPE (EXPANSION VESSEL)	65104253		●	●	●	●																
0325	O-RING 8.9X2.7	61009834-14		●	●	●	●																
0327	EXPANSION VESSEL 8L	65104261		●	●	●	●																
0328	CLIP D:18	65104259		●	●	●	●																
0337	HYDRAULIC GROUP SUPPORT	65104311		●	●	●	●																
0342	CASE PANEL (L.H. SIDE)	65105676		●	●	●	●																
0344	CASE PANEL (FRONT)	65107093		●	●	●	●																
0345	CASE PANEL (R.H. SIDE)	65105677		●	●	●	●																
0363	EXPANSION VESSEL SUPPORT	65104696		●	●	●	●																
				</																			





600






				ECOSI 25 CS CPR ECOSI 24 CA CPR ECOSI 30 CS CPR ECOSI 25 CS SP/A																		31	
	Description	Manf. Pt. N	Type	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	From	to
0600	RETURN GROUP																						
0601	MOTOR (3-WAY VALVE)	61302483-01		•	•	•																	
0602	KIT DRAIN SCREW	60001385		•	•	•	•																
0603	MOTOR + SPRING 3 WAY VALVE KIT	60001583		•	•	•																	
	PLUG	65105093					•																
0604	CLIP	65104331		•	•	•	•																
0605	O-RING 17.04X3.53	65104262		•	•	•	•																
0606	SENSOR (REED)	65104323		•	•	•																	
0607	CLIP	65104332		•	•	•																	
0608	CLIP	65104316		•	•	•	•																
0609	RETURN GROUP	65104335		•	•	•	•																
0610	FILLING TAP KIT	65114261		•	•	•	•																
0611	RIDUCTORS (KIT)	65104318		•	•	•																	
0612	CLIP D:18	65104259		•	•	•	•																
0613	CLIP D:10	65104260		•	•	•	•																
0614	O-RING 5.7X1.9	61009834-10		•	•	•	•																
0615	PRESSURE GAUGE	60000725		•	•	•	•																
0616	CLIP	65104322					•																
0617	O-RING 21.89X2.62	65104320		•	•	•	•																
0618	PIPE (C.H. RETURN)	60001271			•	•																	
	PIPE (C.H. RETURN)	60001276		•			•																
0619	PUMP 5M 2V	65104319		•	•	•	•																
0620	O-RING 17.86X2.62	61308091		•	•	•	•																
0621	LOW PRESSURE SWITCH	65105090		•	•	•	•																
0622	WATER FILTER	60001372		•	•	•	•																
0623	O-RING 9.19X2.62	65104313		•	•	•	•																
0624	CLIP	65100680			•																		
0625	CLIP	60000309		•	•	•	•																
0626	O-RING 7.65X1.78	65104329		•	•	•	•																
0627	O-RING 23.47X2.62	65104315		•	•	•	•																
0628	UNION (3/4»)	65104326		•	•	•	•																
0629	UNION (1/2»)	65104327		•	•	•	•																
0630	D.H.W. PLUG	65105179					•																
	FLOW METER	65104317		•	•	•																	
0631	CLIP	61307589		•	•	•	•																
0632	TEMPERATURE PROBE + CLIP KIT	990686-01		•	•	•	•																
0633	PLUG	65104377		•	•	•	•																
0635	O-RING 15.54X2.62	65104325		•	•	•	•																
0637	O-RING 16,5X1,6	65105180					•																
0638	AUTO AIR VENT WITH O-RING	65104703	WILO	•	•	•	•																
0639	U-CLIP	65104704		•	•	•	•																
0640	O-RING 3X35 EPDM 75 SH	65104705		•	•	•	•																
0641	INTERFACE 'System +' Open	60001365	SYST. +				•																
	INTERFACE 'System' Close	65105181	SYST.				•																
0642	TUBO SYSTEM	60001366					•																
0643	UNION (3/4»-1/2»)	60001367					•																
0644	SHEET GASKET D: 24-14-1.5	60061855-17					•																
0646	EXCHANGER GASKET	65104334					•																
0647	CLIP	65104339		•	•	•																	



700




Gas-wall boiler atm. burner



5000



5005



Gas-wall boiler atm. burner

LIST OF THE ABBREVIATIONS

HW	: Hot water.
CW	: Cold water.
C	: Ceramic resistance (normal heating).
Ca	: Ceramic resistance (accelerated heating)
TP	: Immersion heater.
1F	: With fittings.
2F	: Without fittings.
3F	: With fittings and another outlet connection.
AMI	: With mixing valve.
SMI	: Without mixing valve.
PUISS	: Power of th appliance.
PN	: Appliance with normal pression.
LP	: Appliance with low pression.
PV	: Appliance with variable power.
PF	: Appliance with fixed power.

IDENTIFICATION PLATE

SERIAL NUMBER

10 Characters :	04 05 125 011	Sequential number Manufacturing day Year of manufacture
11 Characters :	1 95 065004 - 31	Technical number of the appliance Sequential number Year of manufacture
Month of manufacture : from 1 to 9 → Jan. to Sep., O → Oct., N → Nov., D → Dec.		
19 Characters :	08 05 0013199 900640031	Product reference Sequential number
Year of manufacture Month of manufacture		
20 Characters :	3675007 XX 2 07 070 00315	Sequential number Manufacturing day Year of manufacture
Product reference Millenium of manufacture		
21 Characters :	3675007 XX 07 070 0000315	Sequential number Manufacturing day
Product reference Year of manufacture		