


SPARE PARTS EXPLODED VIEW
GAS-WALL BOILER ATM. BURNER
Model
ECOSÍ EXT/IN CPR

R8216242-05 - 14/04/2014

ECOSI EXT/IN CPR


Gas-wall boiler atm. burner

1	3314015	ECOSI 25 EXT CS CPR MET	06-2008	-
2	3314016	ECOSI 30 EXT CS CPR MET	06-2008	-
3	3314017	ECOSI 25 IN CS CPR MET	06-2008	-
4	3314018	ECOSI 30 IN CS CPR MET	06-2008	05-2011
Col	Reference	Model type	Begin	End




Gas-wall boiler atm. burner






Gas-wall boiler atm. burner




Gas-wall boiler atm. burner




Gas-wall boiler atm. burner







800



900



5000



Gas-wall boiler atm. burner

LIST OF THE ABBREVIATIONS

HW	: Hot water.
CW	: Cold water.
C	: Ceramic resistance (normal heating).
Ca	: Ceramic resistance (accelerated heating)
TP	: Immersion heater.
1F	: With fittings.
2F	: Without fittings.
3F	: With fittings and another outlet connection.
AMI	: With mixing valve.
SMI	: Without mixing valve.
PUISS	: Power of th appliance.
PN	: Appliance with normal pression.
LP	: Appliance with low pression.
PV	: Appliance with variable power.
PF	: Appliance with fixed power.

IDENTIFICATION PLATE

SERIAL NUMBER

10 Characters :	04 05 125 011	Sequential number Manufacturing day Year of manufacture
11 Characters :	1 95 065004 - 31	Technical number of the appliance Sequential number Year of manufacture
Month of manufacture : from 1 to 9 → Jan. to Sep., O → Oct., N → Nov., D → Dec.		
19 Characters :	08 05 0013199 900640031	Product reference Sequential number
Year of manufacture Month of manufacture		
20 Characters :	3675007 XX 2 07 070 00315	Sequential number Manufacturing day Year of manufacture
Product reference Millenium of manufacture		
21 Characters :	3675007 XX 07 070 0000315	Sequential number Manufacturing day
Product reference Year of manufacture		